


F-PROTEKKT

INSTALLATION GUIDE FOR ELECTRIC PANELS

- After acquiring F-Protekkt, cut the cable ties carefully without hurting the tube
- The packaging consists of cable ties and tube clamps along with rubber linings. Carefully install F-Protekkt with either both or anyone of the fixing materials provided in the protected enclosed space
- We advise strictly to avoid the use of metal fasteners like steel clamp, metal wire etc. for installation of F-Protekkt
- While there are no specific shape rules for installing F-Protekkt, please ensure that the entire space is covered so as to minimise any casualties
- F-Protekkt has a minimum bending radius of 120 mm
- F-Protekkt should be installed in the electric panel so as to provide max coverage



* Above images are for representation purpose only

CAUTION



F-PROTEKKT needs to be installed carefully to get best results



Read instructions carefully before installation



Keep out of reach of children



Do not misuse F-Protekkt

F-PROTEKKT

MAINTENANCE GUIDE

“F-PROTEKKT” system does not require any special maintenance, however some visual inspection is needed to ensure that the product is functional.

- Inspect the pressure gauge is in the green zone each month
- Ensure that the tube is fixed well, and not hanging loose
- Just keep tab of the tube being damaged or not

INSTALLATION & WARRANTY CARD

Buyer Name & Address:	
Panel Location:	
Panel Sr. No.:	
F-Protekkt Batch No.:	
Mfg Date:	
Exp Date:	
Date of Installation:	
Warranty Period:	____ Years
Installed By: (Sign & Stamp)	

Deccaleap Technologies LLP

DECCALEAP HOUSE, S. No. 38, Ahead of Westin Hotel, Next to Nanda Dental Care,
Koregaon Park Annexe, Ghorpadi, Pune, Maharashtra 411001
+91-20-67043838 | www.deccaleap.com

Disclaimer: The manufacturer shall not be liable for any damage to health, life, property or any monetary loss caused due to failure to comply with instructions for installation, use, assembly, maintenance, functional testing, safety instructions, or any other instructions provided in this user manual